

FIG. 1




FIG. 2





FIG. 3



SET EXECUTION CONTROL IN VMCS
TO CAUSE A VM EXIT ON EACH NMI

REQUEST A TRANSFER OF CONTROL TO THE VM

END

FIG. 4




FIG. 5